



3129 PHASE DETECTOR

Field Measuring Instruments

Non-Metallic Contact for Optimal Safety



CE

R

3129 PHASE DETECTOR

HIOK

http://www.hioki.co.jp/

JQA-E-90091 HIOKI col other info

HOKI company overview, new products, environmental considerations and other information are available on our website.

Specifications **Measurement Function** Phase detection (positive, negative), live wire check (R-S/S-T only) Voltage Detection Method Electrostatic induction method Voltage Range 70V to 600V AC (50/60Hz) (sine wave, continuous input) **Clamp** Diameter 17mm max. of insulated wiring Positive: 4 LEDs lit in clockwise order and 3 short beeps Phase Negative: 4 LEDs lit in counterclockwise order and one continuous Detection Display beep Live Wire R-S and S-T lamps will light if voltage between wires are within Check voltage range **Battery Check Function** ON lamp blinks to indicate battery low status when instrument is turned on Auto Power Off Auto shut off if no activity is detected after power is turned ON for 15 minutes Two "AA" size batteries; rated voltage: DC3.0V; maximum rated power: 300mVA; **Power Supply** continuous use: approx. 70 hours (standby) 70W x 75H x 30D mm (2.76"W x 2.95"H x 1.18"D), 200g (7.1 oz); Cord length: **Dimensions**. Mass 0.7m (27.56") 0 to 40°C (32 to 104°F), max. 80% RH (no condensation) **Operating Temperature** Storage Temperature -20 to 60°C (-4 to 140°F), max. 80% RH (no condensation) EN61010-1:2001, EN61010-031:2002 Pollution Degree 2 Safety Standards CAT III 600V (anticipated transient overvoltage 6000V) EN61326:1997+A1:1998+A2:2001 EMC Carrying case x 1, strap x 1, R6P manganese battery x 2, spiral tube x 1, user Accessories manual

Live Wire Check (R-S/S-T only)

Lights up when a live wire is detected

Simply clamp wire with one of the voltage clips to check for voltage



Bright LED and Buzzer Indicate Phase Direction

Positive Phase: 4 LEDs light up in clockwise order along with 3 short beeps



Actual size

Easy clamping over insulated wires of up to 17mm in diameter

Compatible with wires as thick as 100m²

Low Battery Warning and Auto Power OFF Lamp blinks to indicate battery low state Automatically turns off after 15 minutes to save energy



HIOKI E.E. CORPORATION

HEAD OFFICE :

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION : 6 Corporate Drive, Cranbury, NJ 08512 USA TEL +1-609-409-9109 / FAX +1-609-409-9108 E-mail: hioki@hiokiusa.com

Shanghai Representative Office : 1704 Shanghai Times Square Office 93 Huaihai Zhong Road Shanghai, 200021, P.R.China TEL +86-21-6391-0090, 0092 FAX +86-21-6391-00300 E-mail: info@hioki.cn DISTRIBUTED BY

All information correct as of Sep. 29, 2004. All specifications are subject to change without notice